

5



USB WI-FI ADAPTER 600

Boost the Wi-Fi® of your computer!



Installation Instructions
 Installationsanleitung
 Instructions d'installation
 Istruzioni per l'installazione
 Instrucciones de instalación
 Instruções de instalação
 Installatie instructies
 Installationsvejledning
 Installasjonsinstruksjon
 Installationsanvisning
 Telepitési Utasítás

Pokyny pro instalaci
 Inštalacné pokyny
 Instrukcja instalacji
 Upute za postavljanje
 Инструкции за инсталиране
 Instruções de instalação
 Οδηγίες εγκατάστασης
 Kurulum Kılavuzu
 Інструкції по установке
 Інструкції з встановлення

6



SERVICE CENTER

AT	☎ support_at@strong.tv 0820 400 150 (€ 0.12/Min. österr. Festnetz)	FR	☎ support_fr@strong.tv
BG	☎ support_bg@strong.tv +359 32 634451	IT	☎ 199 404 032 Da rete fissa 24,8 cent. al min. 12,5 cent. scatto alla risposta Da rete mobile max 49 cent. al min. 15,6 cent. scatto alla risposta
CEE	☎ support_hu@strong.tv +36 1 445 26 10	NL	☎ support_nl@strong.tv
DE	☎ support_de@strong.tv 0180 501 49 91 (€ 0.14/Min. deutsches Festnetz) (€ 0.42/Min. max. Mobilfunknetze)	PL	☎ support_pl@strong.tv 801 702 017
DK	☎ support_dk@strong.tv	UA	☎ support_ua@strong.tv +380 (44) 238 61 50

www.strong.tv

1




← → ↻ | <http://www.strong.tv/wifi-adapter600>

<http://www.strong.tv/wifi-adapter600>

2





3



USB600_Windows_Setup.exe

4



USB600_Windows_Setup.exe

